


# Wet Film Comb



Measuring Procedure:

- 1. Select comb according to approximate thickness.
- 2. Hold comb perpendicular to coating to be measured.
- 3. Press into coating until the comb stands square.
- 4. Wet film thickness is between the highest step coated and the next (higher) step remains uncoated.

Model: CM-2000 CM-8000

Applications

Used for checking the coating thickness of wet paint, enamel lacquer, adhesive, architectural coating, color coating, varnish, chemical industry, or other coating that has been applied to a smooth surface.

Specifications

Model	CM-2000
Standards	GB/T1764-79 GB/T134522-92 ISO2808-74
Range	25~2032μm / 1~80mil
Values	25, 51, 75, 102, 127, 152, 178, 203, 229, 254, 279, 305, 356, 406, 457, 508, 559, 610, 660, 711, 762, 889, 1016, 1143, 1270, 1397, 1524, 1651, 1778, 2032μm 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 35, 40, 45, 50, 55, 60, 65, 70, 80mil

Model	CM-8000
Standards	GB/T1764-79 GB/T134522-92 ISO2808-74
Range	25~3000μm / 1~118mil
Values	25, 50, 75, 100, 125, 150, 175, 200, 225, 250, 275, 300, 350, 400, 450, 500, 550, 600, 650, 700, 750, 800, 850, 900, 1000, 1100, 1200, 1400, 1600, 1800, 2000, 2200, 2400, 2600, 2800, 3000μm 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 31, 33, 35, 39, 43, 47, 55, 63, 71, 79, 87, 94, 102, 110, 118mil